



baja designs®
The Scientists of Lighting

'09-'18 Dodge Ram 1500 (2019 Classic) A-Pillar mount kit Instructions



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
The Scientists of Lighting

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.



baja designs
The Scientists of Lighting

Silverado Universal 20" S8/OnX6 bracket kit

Tools Required

4mm Allen wrench (Ball hex preferred)

10mm Socket wrench

Masking tape

Writing instrument

1. Begin by gently pulling back the rubber cowling nearest the bottom corner of the windshield. Notice the 10mm hex head upper fender fastener. Remove the bolt with a 10mm socket wrench and this threaded hole will be used to mount the A Pillar bracket.



2. Place masking tape as shown.





baja designs
The Scientists of Lighting

3. Place the M6 Button head bolt through a ¼" washer and the slotted hole on the inside of the bracket. While applying mild pulling force to the top of the fender as shown, use the 4mm Allen wrench to carefully thread the bolt into the hole. Take care not to cross thread the factory threaded hole. If it becomes difficult to tighten while a decent portion of the threads are still exposed, completely remove and try again until it goes in smoothly.



4. Once it is confirmed that the threads are engaged properly, reverse the bolt until the bracket has a small amount of play. Place the rubber pad inbetween the bracket and the fender. Trace the outline of the sides of the bracket and the top of the fender. Cut pad and remove adhesive backing. Adhere pad to inside of upper fender. Torque the bolt snug. Repeat steps 1 through 4 for the opposite side of the vehicle.



Re-torque all fasteners after 100 miles.

See the instructions supplied with the wiring harness to complete wiring needs.

Your install is now complete! Thank you for choosing Baja Designs.